

## Rubber Hose (reusable)

### Hose Sleeve



Sloan No.	Hose Size
S360AB-6•	3/8
S360AB-8	1/2

### Union Body



Sloan No.	Hose Size
S362RB-6B	3/8
S362RB-8B	1/2

### Male Connector



Sloan No.	Hose Size	Pipe Thread
S368AB-6-4•	3/8	1/4
S368AB-6-6•	3/8	3/8
S368AB-6-8•	3/8	1/2
S368AB-8-6	1/2	3/8
S368AB-8-8	1/2	1/2

### Hose Nut



Sloan No.	Hose Size
S361AB-6	3/8
S361AB-8	1/2

### Female Swivel Connector w/Adapter



Sloan No.	Hose Size	Thread ABS	Size Pipe
S363RB-6	3/8	3/8	1/4
S363RB-8	1/2	1/2	3/8

### Male Connector Body



Sloan No.	Hose Size	Pipe Thread
S368AB-6-4-1	3/8	1/4
S368AB-6-6-1	3/8	3/8
S368AB-6-8-1	3/8	1/2
S368AB-8-6-1	1/2	3/8
S368AB-8-8-1	1/2	1/2

### Nut Less Spring Guard



Sloan No.	Hose Size
S361ABS-6	3/8
S361ABS-8	1/2


For use with 371AS Spring Guard.

### Female Swivel Connector



Sloan No.	Hose Size
S366RBSV-634	3/8
S366RBSV-878	1/2

### Nut w/Spring Guard



Sloan No.	Hose Size
S371ABS-6	3/8
S371ABS-8	1/2

### Union



Sloan No.	Hose Size
S362RB-6	3/8
S362RB-8	1/2


### Female Swivel Connector Body



Sloan No.	Hose Size	Pipe Thread
S366RBSV-634B	3/8	3/4
S366RBSV-878B	1/2	7/8

## Rubber Hose (reusable)

### Spring Guard



Sloan No.	Hose Size
S371AS-6	3/8
S371AS-8	1/2

For use with 361ABS Nut.

### Adapter



Sloan No.	Pipe Size	Straight Thread
S376AB-3/4-4	1/4	3/4-20
S376AB-3/4-6	3/8	3/4-20
S376AB-7/8-6	3/8	7/8-20
S376AB-7/8-8	1/2	7/8-20
S376AB-3/4-8	1/2	3/4-20

\*Note: These adapters are used on Sloans air brake hose assembly swivel ends, See page 12 for Sloan's wide selection of air brake hose assemblies.

### Male Connector w/Spring Guard



Sloan No.	Hose Size	Pipe Thread
S378AB-6-4•	3/8	1/4
S378AB-6-6•	3/8	3/8
S378AB-6-8•	3/8	1/2
S378AB-8-6	1/2	3/8
S378AB-8-8	1/2	1/2